

EasySoaker Boot Sizing


Important: EasyCare recommends sizing up when purchasing an EasySoaker. Sizing up one to two sizes allows extra space for bandages and liquids to be used inside the boot. In addition, a larger size makes application and removal quicker and easier.

Size	Width in inches	Length in inches	Size	Width in mm	Length in mm
Small	3 3/4" - 4 1/2"	4 1/4" - 5"	Small	95-115 mm	108-127 mm
Medium	4 1/2" - 5 1/4"	5" - 5 3/4"	Medium	115-134 mm	127-146 mm
Large	5 1/4" - 5 3/4"	5 3/4" - 6 1/4"	Large	134-146 mm	146-159 mm
X-Large	5 3/4" - 6 1/4"	6 1/4" - 6 3/4"	X-Large	146-159 mm	159-172 mm
XX-Large	6 1/4" - 6 3/4"	6 3/4" - 7 1/4"	XX-Large	159-172 mm	172-184 mm
XXX-Large	6 3/4" - 7 1/4"	7 1/4" - 7 3/4"	XXX-Large	172-184 mm	184-190 mm

Note: We recommend that a veterinarian diagnose any lameness or hoof problems.

How to get the correct size boot for your horse:

To determine the proper size boot for your horse, measure the width of the affected hoof, across the bottom at the widest point and from toe to heel. Choose from the recommended EasySoaker size charts below



We recommend that the horse be restrained or confined while you are soaking, as the boot is loose fitting and may come off if the horse moves around.

